



OPERATING INSTRUCTIONS

Part List



A 2pcs



B 2pcs



C 2pcs



D 1pc



E 1pc




F 2pcs



Part	Description	QTY
H	M6x60	4
I	M6x35	8
J	M6x50	8
K	M6x70	4
L		20
M		8
N		24
O		24
P		24
Q		1
R		1

Assembly Instructions

Step 1



Step 2



Step 3



Step 4

