

Telescopic Gutter Cleaner INSTRUCTIONS

1. Attach head by screwing on to handle, ensure this is done tightly so that it does not become loose when using.
2. Loosen telescopic handle lock by twisting anti-clockwise.
3. Adjust to required length and tighten by turning the handle clockwise.
4. Use paddle end of cleaner to move debris from your guttering.
5. Take extreme care whenever working overhead and take appropriate precautions to ensure your safety.

