


Assembly Instruction

1.




Remove the lid and look inside the bin, to find a polybag containing 3 legs of this product and hardware in it.

2.



Remove the hardware and legs from the polybag attached to the inside of the Incinerator Bin.

3.



Use these screws and nuts to fix these 3 legs (one by one) from outside

4.



Cover the bin with lid and your incinerator is ready to use

Before using a garden incinerator, you should make sure that your house doesn't lie in a smokeless zone, you are allowed to burn rubbish in your yard and your neighbours are not uneasy with the smoke the wind may carry to their homes.

First line the bottom of the incinerator with crunched-up newspapers and put some small twigs on top of that. Before actually lighting the incinerator, make sure that the ventilation holes at the bottom are open enough. Without good ventilation, your fire will keep dying out. Light it and give it a bit of time to heat up, after which you can add some bigger branches. Make sure that you place the garden incinerator somewhere in the open and safe place where fire accidents won't happen easily and provisions for fire fighting are handy.