

USERS

TREE STAND



1 START

Check that all branches 25cm from the bottom of the tree are removed. Hold the trunk of the tree and push the tree towards the spike in the bottom of the stand. Make sure that the tree is in a straight position.


2 POSITION

Push the tree until it rests on the top of the spike. Hold the tree in a firm grip to make sure that it remains straight. Lift the tree together with the stand a few inches from the floor--push it firmly against the floor, placing the tree onto the brass spike. (Make sure you have a cover underneath). Fill water in the tank.



3 RELEASE

Hold the tree in a firm grip with both hands, place one foot on stand for support and turn the trunk anti-clockwise until it is in a free position. Lift out.



The size of the tree

Water Reservoir 4.5L.

GARDENISED

User's Manual

EGANT Christmas Tree Stand

The stand is extremely easy to use. By following the basic procedures listed below you will have a trouble-free Christmas with your Christmas tree.

Designed for trees with a maximum height of 2.8 meters and with a diameter at the cut level from 4 to 11 centimeters.

The stand is only suitable for indoor use. The insertion of the tree and the handling of the stand should only be carried out by adults.

The Christmas tree must be cut horizontally (square cut) and 25 centimeters of the lower part of the trunk must be clean of branches before insertion into the stand.

The stand should be placed on a protective floor covering.

Before you insert the tree make sure that the fastening device is placed in the START position--as illustrated. The spring holders are fitted with protective caps in order to prevent injury from the sharp edges of the spring. These protection caps must be removed before you start using the stand.

If the fastening device is not in the START position, the spring holders must be tilted inwards, and together with the movable ring (to which they are connected) be turned clockwise, until they are in the START position. In handling the spring holders make sure only to touch the plastic part to avoid injury.

Insert the tree into the stand until just above the spike, which is placed in the bottom of the water reservoir.

Adjust the vertical position of the tree.

Raise the tree 3-4 centimeters.

Push the tree forcefully into the tree stand, thus ensuring that the spike penetrates the base of the tree trunk.

After erecting the Christmas tree fill up the water reservoir. The reservoir will hold up to 1 litre of water. Fill regularly to ensure that your tree stays fresh over the festive period.

Should you overfill the water reservoir any excess water will spill into the water trench at the base of the stand.

After Christmas to remove the stand is a very simple procedure. Hold the tree with one hand, place your foot on the groove at the base of stand. (See illustration). Turn the tree anti-clockwise as indicated by the arrow (OPEN). This will release the fastening springs from the tree. You can now simply remove the tree from the stand by lifting vertically.

The stand can be cleaned by simply using a mild household detergent.

IMPORTANT: Do not let candles burn on the tree unless under continuous supervision by adults.

Should the above instructions not be followed the guarantee will become invalid.

ILLUSTRATION: Please see front page.

By **Quickway Imports** inc.