



## \* PRODUCT INFORMATION



The pets keep the food from the leakage holes by turning the slow feeder. And then through the bottom of the plate to control the dog eating speed.



Place where pet food is stored Put the pet food from the hole and then close it



Height adjustment knob Suitable for different sizes of pets to eat and play



3 Different sizes of the leakage hole

It can make different sizes of pet food fall from the leakage hole

